WISESCENE 350mA

350mA 3 x 7W
Quicklink: Q1D8D

General

Construction	Plastic
IP Rating	IP20
Maximum Addresses	20
Maximum Scenes Per Receiver	64
Maximum Switches Per Receiver	16
Minimum Spacing Between Receivers	200mm
Radio Frequency	868.3 MHz
Range for Metal Switch	50m Max line of sight (subject to installation)
Range for Plastic Switch	100m Max line of sight (subject to installation)

Dimensions

Height	35mm
Length	165mm
Width	47mm

Electrical

Amperage	350mA
Input Voltage	24V DC
Maximum Wattage	21
Maximum Wattage	21W (3 x 7W)
Minimum Wattage	1

The **Wise Scene 350mA Receiver** is a 3 x 7W 350mA dimmer that is controlled by wireless switches or by a push-to-make switch. It can dim 350mA LEDs. It can be programmed in 4 different ways using our wireless switches:

Option A - Scene Programming
Programming a 7 button switch gives you 4 scenes, master raise/lower and off. A scene is a preset level of light for each circuit in a room. For example, you can have 4 receivers in your living room. Pressing scene 1 on the 7 button switch could give the following;
Downlights = 100%
Wall lights = 80%
Pendant = Off
Low level LEDs = 55%
Pressing scenes 2,3 and 4 can give other preset levels. Any level can be programmed to each receiver.

Option B - Dimming Programming
Programming a 1 button switch gives you on/off with a quick press and dimming up and down while holding the switch. When turning the lights on you can choose to always bring on the lights at 100% or the last dimmed level.

Option C - Switching ON only
Programming a 1 button switch gives you only ON. This function is used to program multiple circuits to ON.

Option D - Switching OFF only
Programming a 1 button switch gives you only OFF. This function is used to program multiple circuits to OFF.

A receiver is not limited to one of the programming options. E.g. you can program a switch for scene control, another switch for dimming and another switch for master ON/OFF.

Wireless Switches and Remotes
A 7 button switch must be used if you require scene setting, Option A. Any button switch can be used when programming options B,C and D. To view other switches click the links on the right of this page, for example Wireless ID switches.

Power Supply
The Wise Scene Receiver requires a 24V DC power supply. Choose the wattage of the

power supply that matches your load.

A wired push-to-make switch will work as a dimmer, Option B.

A Wise Scene Receiver is required for every circuit.

Wise Controls Introduction Video