



WISESCENE SWITCH

240V 800W
Quicklink: Q1D2F

General

Construction Plastic
IP Rating IP20

Maximum Addresses 20
Maximum Scenes 64
Per Receiver
Maximum Switches 16
Per Receiver
Minimum Spacing 200mm
Between Receivers
Radio Frequency 868.3 MHz
Range for Metal Switch 50m Max line of sight (subject to installation)
Range for Plastic Switch 100m Max line of sight (subject to installation)

Dimensions

Height 35mm
Length 165mm
Width 47mm

Electrical

Input Voltage 240V
Maximum Wattage 800W
Minimum Wattage 1W
Output Voltage 240V

The **Wise Scene Switch Receiver** is an 800W 240V switch that is controlled by wireless switches or by a push-to-make switch.

Please Note:

The current iteration of this product has a 3 second on/off delay in scene (Option A) and switching (Option B) programming modes. Switching ON (Option C) and switching OFF (Option D) only programming does not have a 3 second delay, but please note that these options cannot be programmed on the same button.

It can be programmed in 4 different ways using our wireless switches:

Option A - Scene Programming

Programming a 7 button switch gives you 4 scenes, master raise/lower and off. A scene is a preset level of light for each circuit in a room. For example, you can have 4 receivers in your living room. Pressing scene 1 on the 7 button switch could give the following;

Downlights = ON or OFF

Wall lights = ON or OFF

Pendant = ON or OFF

Low level LEDs = ON or OFF

Pressing scenes 2,3 and 4 can give other preset levels. Any level can be programmed to each receiver.

Option B - Switching Programming

Programming a 1 button switch gives you on/off.

Option C - Switching ON only

Programming a 1 button switch gives you only ON. This function is used to program multiple circuits to ON.

Option D - Switching OFF only

Programming a 1 button switch gives you only OFF. This function is used to program multiple circuits to OFF.

A receiver is not limited to one of the programming options. E.g. you can program a switch for scene control, another switch for dimming and another switch for master ON/OFF.

Wireless Switches and Remotes

A 7 button switch must be used if you require scene setting, Option A. Any button switch can be used when programming options B,C and D. To view other switches click the links on

the right of this page, for example Wireless ID switches.

A wired push-to-make switch will work as a dimmer, Option B.

A Wise Scene Receiver is required for every circuit.

Wise Controls Introduction Video

